
- 20. A limited number of 1/4" rollers are available that have a "wide" throat that is good for rippled and thicker glass that will not fit into the 1/4" roller that is furnished. See your local stained glass dealer.
- 21. A "Magic Cutter™ is now available. It is faster and easier to use than a scissors. It adjusts roller height and consistently leaves the foil in the roller ridges for the next piece of glass.
- 22. ROLLER MAINENANCE may be necessary especially after using thicker glass. The roller is made in two pieces and may spread apart which results in inconsistent foil application and poor crimping.

To check your rollers, compare with the drawing by holding the roller up to light.



If spread apart, step on the roller to force together or to make permanent:

- 1. Pull sides apart with your fingers, leave "O" ring on.
- 2. Put small amount of plastic glue (epoxy, super glue, etc.) in the two small holes (not the big hole)
- 3. Mate the sides and step on roller with all your weight to mate completely